

## The activation of the trailer functions has to be carried as follows:

1. Connect computer to car
  2. Start program
  3. Click "Special functions"
  4. Click "Input for retrofits or conversions"
  5. Enter you user name and password
  6. Write 550 in the upper (+) field
  7. Accept and close the program.
  8. Start the program again
  9. Click "Controllers View"
0. Click "**EZS**" (Ignition)
  1. Click "Adjust"
  2. On the left side: click Configuration SCN encoding
  3. Go online a wait a few seconds
4. Click "**SAM-rear**" (Signal detection- and control modul rear).
  5. Click "Adjust"
  6. On the left side: click Configuration SCN encoding
  7. Go online a wait a few seconds
18. Click "**SAM-front**" (Signal detection- and control modul front).
  19. Click "Adjust"
  20. On the left side: click Configuration SCN encoding
  21. Go online a wait a few seconds
22. Click "**combined instrument**"
  23. Click "Adjust"
  24. On the left side: click Configuration SCN encoding
  25. Go online a wait a few seconds
26. Click "**headunit**"
  27. Click "Adjust"
  28. On the left side: click Configuration SCN encoding
  29. Go online a wait a few seconds
- if "360° camera" is fitted:**
30. Click "**360° camera**"
  31. Click "Adjust"
  32. On the left side: click Configuration SCN encoding
  33. Go online a wait a few seconds

►| **Coding finished**