

FITTING INSTRUCTIONS



PART NUMBER: T2Z571

Hyundai Elantra - 2011 – on
Towing Capacity 1300 Kg / Ball Load 130 Kg
Lug # L211

- 1) Remove 3x phillips screws from around wheel arch on both sides
- 2) Remove 7x plastic clips from under side of bumper
- 3) Remove tail lights by undoing 3x 10mm nuts from behind tail light each side
- 4) Remove 1x phillips screw both sides under tail lights
- 5) Remove 2x 14mm bolts from under side of vehicle that hold impact beam in place
- 6) Remove bumper and remove the 3x plastic hangers on the bottom of the impact beam.
- 7) Offer tow bar to vehicle and loosely fit all bolts then tighten.
- 8) Mark bumper from center line mark out 120mm on passenger side and 45mm on driver's side and 30mm deep and the remove.
- 9) Refit bumper and tail lights.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8