

# FITTING INSTRUCTIONS

PART NUMBER: **T2F145**



Ford Falcon Wagon AU Series & BA 09/98 - on  
Towing Capacity 1600Kg / Ball Load 160Kg  
Lug # L213

1. Remove bumper pop out.
2. Feed tow bar behind bumper by starting on the driver's side, up over the bumper bar mount, slide across and put on the end of the chassis rail. You will have to move exhaust to fit up behind chassis rail.
3. Fit 8 x 10mm bolts with washers through end of chassis rail with rectangle plates on the front side of chassis rail with washers and nuts.
4. Tighten all bolts to torque settings.
5. Fit tongue with bolts supplied.
6. Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY**  
**TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b><u>Nm</u></b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8