

FITTING INSTRUCTIONS



PART NUMBER: **T4H436**

ISUZU DMAX UTE S/SIDE WITH STEP

07/08 to 06/12

Towing Capacity 3000 Kg / Ball Load 300 Kg

Lug # L4045

- 1) Remove rear step.
 - a) Disconnect number plate lights.
 - b) Remove 6x M12 bolts holding rear step.
- 2) Fit towbar to bottom of chassis using 4x M10 bolts & washers into captive nuts.
- 3) Feed plates on wire into chassis rail to line up with holes on the inner side of the chassis rail and towbar.
- 4) Fit 4xM12 bolts and washers through towbar into plates on wire.
- 5) Tighten all bolts to torque settings below.
- 6) Re fit rear step.
- 7) Fit ball mount with pin & clip supplied.
- 8) Fit door sticker supplied to door.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8