

FITTING INSTRUCTIONS

PART NUMBER: **T4H432**



HOLDEN RODEO UTE C/CHASSIS & S/SIDE WITHOUT STEP

02/03 to 06/12

Towing Capacity 3000Kg / Ball Load 300Kg
Lug # L4045

- 1) Remove towing hook.
- 2) Fit tow bar to outside of chassis rail using 6 x M12 x 1.25 bolts and washers into captive nuts.
- 3) Fit 4 x M10 x 1.25 bolts and washers into bottom of chassis rail with angle bracket.
- 4) Fit 4 x M10 bolts, nuts and washers through angle brackets and tow bar.
- 5) Tighten all bolts to torque listing.
- 6) Fit ball mount with pin & clip supplied.
- 7) Fit door sticker supplied to door.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8