# **Fitting Instructions**



SKU

PRODUCT

## T4H597

## TAG Heavy Duty Towbar to suit Isuzu D-MAX (06/2012 - 07/2020)





Scan for latest version of these instructions

### SPECIFICATIONS

- Towbar Class: Heavy Duty
- Towing Capacity: 3500kg

#### IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

## **Towbar Fitting Instructions**



### **Step-By-Step Instructions**

#### Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

#### General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure, then ask your towbar supplier.

Tighten all bolts as specified on the last page.

- 1. Remove rear step first, unplug number plate wiring on passenger side.
- 2. Undo 3x17mm bolts on both sides and remove step.
- 3. Place metal plates with nuts welded to them, inside chassis rail lined up with holes.
- 4. Align towbar to the car with mounting points on outside of chassis and secure with 3x18mm bolts from outside of chassis rails into captive threads on both sides.
- 5. Using 2x16mm bolts, secure from underneath the chassis rail into threaded plates on both sides. Then tighten all bolts.
- 6. Remove mounts off step by unclipping plastic cover on step, then undo 2x13mm bolts and 1x10mm bolt at each end.
- 7. Place step on mounted towbar and with 2x14mm bolts supplied, re-attach step and mount the two brackets supplied at each end.
- 8. Tighten all bolts and put plastic cover back on step.

## **Towbar Fitting Instructions**



### Torque table for bolt tightening

Metric GRADE 8.8
M6 – 9.5 Nm
M8 – 21.7 Nm
M10 – 43.4 Nm
M12 – 77.3 Nm
M16 – 189.8 Nm

### **TAG Warranty Statement**

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au