

FITTING INSTRUCTIONS



PART NUMBER: **T2D462**

Nissan XTrail T30 Wagon 10/01 to 09/07
Towing Capacity 1200 Kg / Ball Load 100 Kg
Lug # L266c

- 1) Remove bumper.
 - a) Lift Tailgate.
 - b) Remove 2 bolts from behind tailgate holding bumper.
 - c) Remove 4 screws from each wheel arch, 1 at the top, 1 from underneath and 2 from behind splash guard up into quarter panel.
 - d) Remove plastic cover from underneath and discard.
 - e) Remove 2 scrivenets from bottom of bumper.
- 2) Remove crash cans.
- 3) Remove spare wheel and spare wheel cover from inside of boot.
- 4) Fit towbar to vehicle by the bottom of the chassis rail on driver's side and the inner-side of the chassis rail on the passenger side.
- 5) Fit 2x M12 bolts on wire with square plates through rear holes in chassis rail to line up with rear holes in towbar. Fit nuts & washers supplied.
- 6) Fit 2x M12 bolts on wire with square plates through holes in chassis rail to line up with forward holes in towbar. Fit nuts & washers.
- 7) Using the towbar as a guide, drill 2x 11mm holes into wheel well.
- 8) Fit 2x M10 bolts & plates through drilled holes and fit nuts & washers from underneath.
- 9) Tighten all bolts to torque listing below.
- 10) Re fit bumper.
- 11) Re fit spare wheel and cover.
- 12) Fit tongue with bolts supplied.
- 13) Fit door sticker supplied to door.

FITTING INSTRUCTIONS

PART NUMBER: **T2D462**



RECOMMENDED ASSEMBLY TORQUE LISTIN

<u>Diameter</u>	<u>G</u>	<u>Grade 8.8 Bolt</u> <u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8