

# FITTING INSTRUCTIONS



PART NUMBER: T4D003

Nissan Pathfinder 4WD 10/95 →

6/05

Towing Capacity 2000 Kg / Ball Load 200 Kg

Lug # L4120

- 1) Remove towing hook.
- 2) Fit towbar to outside of chassis using 3x M12 bolts & washers into captive nuts.
- 3) Make sure spacer plate is fitted in-between chassis rail and towbar.
- 4) Fit M8 bolts & washers onto under side of chassis rail into captive nuts.
- 5) Use towbar as guide, and drill 2x 11mm holes.
- 6) Fit M10 bolt on wire into chassis rail and through hole. Fit nuts & washers.
- 7) Tighten all bolts to torque listing below.
- 8) Fit ball-mount with pin & cup supplied.
- 9) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY  
TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8