

FITTING INSTRUCTIONS



PART NUMBER: T2F175

Ford Falcon Sedan BA - FG - 10/02 on
Towing Capacity 1600Kg / Ball Load 160Kg
Lug # L264

- 1) Remove bumper
 - 1a) Remove scrivets and screws from wheel arch on each side.
 - 1b) Carefully flex bumper side ways to unclip
 - 1c) FG models remove tail lights and remove scrivets
 - 1d) BA-BF models remove 4 x 10mm nuts of studs to release bumper bar.
These are located behind trim on either side.
 - 1e) Remove scrivets from underside of bumper.
- 2) Fit tow bar to vehicle using 4 x 10mm corflex bolts.
- 3) Fit nylok nut and washer to stud on left hand side of under chassis.
- 4) Fit tapped plates into rear of vehicle to line up with tow bar tabs and fit 2 x 12mm bolts and washers.
- 5) Tighten all bolts to torque listing.
- 6) Pop out bumper insert and refit bumper.
- 7) Fit tongue with bolts supplied and tighten.
- 8) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8