

FITTING INSTRUCTIONS



PART NUMBER: T4D469

Nissan Pathfinder 07/05 – on
Towing Capacity 3000 Kg / Ball Load 300 Kg
Lug # L4045

- 1) Remove 2x bolts from exhaust. Remove impact beam buy removing 3x bolts from each side. Offer towbar to vehicle to see if it requires a cut out. **(Note: as bumper profiles can change please check your measurements before cutting to make sure the dimensions are correct).**
- 2) If so mark out center of bumper on under side, mark 100mm each side of center line and come in 25mm. cut out section and discard. Offer tow bar to vehicle and fit all bolts.
- 3) Drill 4x 13mm holes up through chassis, feed tapped plates on wire up into chassis and line up with drilled holes, fit bolts and tighten.
- 4) Refit exhaust bolts and tighten.



RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8

FITTING INSTRUCTIONS

PART NUMBER: T4D469

