

FITTING INSTRUCTIONS



PART NUMBER: T2H431

Holden Rodeo Ute Cab Chassis & Style Side 02/03 to 06/12

Towing Capacity 1200Kg / Ball Load 100Kg

Lug # L264

- 1) Remove towing hook.
- 2) Fit tow bar to outside of chassis rail using 6 x M12 x 1.25 bolts and washers into captive nuts.
- 3) Fit 4 x M10 x 1.25 bolts and washers into bottom of chassis rail with angle bracket.
- 4) Fit 4 x M10 bolts, nuts and washers through angle brackets and tow bar.
- 5) Tighten all bolts to torque listing.
- 6) Fit tongue with bolts supplied.
- 7) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8