

Make / Model HOLDEN COMMODORE VE UTE

Other

Year 07 TO 2013

Part number T4H465

Maximum towing capacity 1600 kg

Maximum ball load 160 kg

Bar weight 26 kg

Fit with wiring harness part No.

Fitting Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR TAKING NOTE OF LOCATIONS AND ASSEMBLY.
 - 1.1. REMOVE SCREWS AND SCRIVETS FROM WHEEL ARCHES AND UNDERSIDE REAR OF BUMPER.
 - 1.2. REMOVE BUMPER PULLING OUT AT SIDES FIRST THEN REARWARD FROM MIDDLE.
 - 1.3. DROP EXHAUST FROM REAR HANGERS.
 - 1.4. REMOVE BOTTOM BOLT FROM EACH TAILGATE HINGE.[RETAIN]
2. FIT TOWBAR ONTO VEHICLE SECURING WITH ½ INCH BOLTS, PLATES AND WASHERS SUPPLIED THROUGH REAR FACING PANEL. [ASSISTENCE RECOMMENDED]
 - 2.1. FIT TAPPED PLATES ON WIRE INTO SUBFRAME FOR FORWARD HOLES OF TOWBAR USING EXISTING HOLE IN SUBFRAME AND SECURE WITH ½ INCH BOLT AND WASHERS FROM UNDERNEATH.
 - 2.2. FIT LAST ½ INCH BOLTS AND PLATES INTO EXISTING HOLE OF SUBFRAME FOR OUTER HOLE OF TOWBAR AND SECURE WITH NUTS AND WASHERS SUPPLIED FROM UNDERNEATH.
 - 2.3. FIT BOLTS REMOVED INTO CAPTIVE NUTS OF TAILGATE HINGE.
 - 2.4. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.
3. REFIT EXHAUST BACK ONTO REAR HANGERS.
 - 3.1. BUMPER CUT OUT TO BE DONE BEFORE REFITTING. **[ORIGINAL FACTORY MARKINGS]**
4. FIT BALL MOUNT WITH PIN AND CLIP SUPPLIED.
 - 4.1. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

Torque table for bolt tightening

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	