

FITTING INSTRUCTIONS



PART NUMBER: **T2A498**

Honda Accord Sedan and Euro 06/03 to 01/08
Towing Capacity 1200 Kg / Ball Load 120 Kg
Lug # L267

- 1) Remove bumper bar.
 - 1.a) Remove three screws from each wheel arch.
 - 1.b) Gently pull bumper away from vehicle to release plastic cups.
 - 1.c) Remove two plastic scrivets from bottom of bumper bar.
 - 1.d) Remove two plastic covers near tail lights and remove two bolts holding bumper.
 - 1.e) Gently unclip bumper from vehicle.
 - 1.f) Remove plastic cover from under vehicle.
- 2) Remove impact beam and discard.
- 3) Fit tow bar to vehicle via 6 x M8 bolts and washers.
- 4) Remove spare wheel.
- 5) Using tow bar as guide, drill an 11mm hole through spare wheel well.
- 6) From inside of boot open up hole just drilled to fit spare tube.
- 7) Fit bolt and plate into spare wheel well, and down through tow bar.
- 8) Fit nut and washer.
- 9) Tighten all bolts to torque listing.
- 10) Do bumper cut. Find centre of bumper and measure 40mm either side and 30mm from edge of bumper.
- 11) Cut plastic cover to fit around tow bar.
- 12) Refit bumper bar.
- 13) Refit plastic cover.
- 14) Refit spare wheel
- 15) Fit tongue with bolts supplied.
- 16) Fit door sticker supplied to door.

<u>RECOMMENDED ASSEMBLY</u>	
<u>TORQUE LISTING</u>	
<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8