

# FITTING INSTRUCTIONS



PART NUMBER: **T4C529**

Mitsubishi Challenger 4WD 2009 onwards  
Towing Capacity 2500 kg/ Ball Load 250kg  
Lug # L4120

- 1) Remove shipping hook.
- 2) Remove bumper tab scrivet.
- 3) Push bumper tab mounting bracket forward.
- 4) Slide angle brackets down chassis rail and fit 2x M12 bolts, washers & nuts. Fit 2x M12 bolts on wire down chassis rail through angle bracket and through side of chassis rail. Fit washers & nuts.
- 5) Lift towbar to bottom of chassis and fit 2x M12 bolts down through angle bracket, through chassis rail and through towbar. Fit nuts & washers and tighten.
- 6) Tighten angle bracket bolts through side of chassis rail.
- 7) Using towbar as guide, drill 4x 13mm holes.
- 8) Fit bolt on welded plate & wire into forward hole on each side.
- 9) Fit bolt on welded washer & wire into remaining hole.
- 10) Fit nuts & washers to all bolts and tighten.
- 11) Tighten all bolts to torque listing below.
- 12) Cut off any exposed wire welded to bolts.
- 13) Fit ball mount with pin & clip supplied.
- 14) Fit door sticker supplied to door.

**ECU MUST BE FITTED WITH THIS TOW BAR**  
**ECU SOLD SEPARATELY**

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8