

Make / Model VW TOUREG

Other

Year 9/03-ON

Part number T4P532

Maximum towing capacity 3500 kg

Maximum ball load 350 kg

Bar weight 24 kg

Fit with wiring harness part No. EL5541

Fitting Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE OF BUMPER.
 - 1.1. REMOVE TORQUE SCREWS AND SCRIVETS FROM WHEEL ARCHES AND UNDERSIDE REAR OF VEHICLE.
 - 1.2. REMOVE BUMPER REARWARDS AND PLACE ON STAND.
2. REMOVE IMPACT BEAM [DISCARD], KEEP 8 X ORIGINAL BOLTS.
3. INSTALL TOWBAR USING 8 X ORIGINAL BOLTS AND TIGHTEN TO SPECIFIED RATINGS.
 - 3.1. REINSTALL BUMPER BACK ONTO VEHICLE.
4. FIT BALL MOUNT WITH PIN AND CLIP PROVIDED.
 - 4.1. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

METRIC GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

Torque table for bolt tightening