

Make / Model FORD KUGA

Other

Year

Part number T2F609

Maximum towing capacity 750 kg

Maximum ball load 75 kg

Bar weight 17 kg

Fit with wiring harness part No. EL5540

Fitting Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

MAKE / MODEL / YEAR

1. REMOVE OF BUMPER.
 - 1.1. REMOVE ALL SCRIVETS AND SCREWS FROM WHEEL ARCHS AND UNDERSIDE OF VEHICLE.
 - 1.2. REMOVE TAIL LIGHTS.
 - 1.3. REMOVE BUMPER PULLING OUT AT SIDES THEN REARWARDS/PLACE ON STAND.
2. REMOVE IMPACT BEAM AND DISCARD.
 - 2.1. REMOVE ALL BOLTS FROM TOW BAR.
 - 2.2. FIT SIDE ARMS INTO SUBFRAME AND BOLT USING 4 XM10 BOLTS PLATES AND WASHERS THROUGH EXISTING HOLES OF VEHICLE.[these holes can be covered by sticker]
 - 2.3. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS
3. REFIT BUMPER AND TAIL LIGHTS.
4. FIT BALL MOUNT WITH 2 X M16 BOLTS AND WASHERS AND TIGHTEN.
 - 4.1. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

Torque table for bolt tightening