

Make / Model TUNLAND

Other

Year 2012-ON

Part number T41001

Fit with wiring harness part No. EL5804

Maximum towing capacity 2500 kg

Maximum ball load 250 kg

Bar weight 30 kg

Fitting Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOW BAR TAKING NOTE OF LOCATIONS AND ASSEMBLY.
2. FIT TOW BAR ONTO VEHICLE SECURING WITH 4 X M12 BOLTS AND HARDWARE THROUGH SIDE REAR HOLES IN CHASSIS RAILS, 2 X M12 BOLTS WITH PLATES ON WIRE AND WASHERS THROUGH FORWARD SIDE HOLE, LASTLY 4 X M10 BOLTS AND NUTS WITH PLATES AND WASHERS THROUGH REAR BOTTOM SECTION OF CHASSIS.
3. MODELS FITTED WITH REAR BUMPER WILL NEED TO REMOVE BUMPER FIRST AND FIT 2 X SPACER PLATES PROVIDED BETWEEN SIDE ARM BRACKET AND BUMPER BAR MOUNT ON BUMPER.

3.1. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS

4. FIT BALL MOUNT WITH PIN AND CLIP SUPPLIED.
5. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

Torque table for bolt tightening