

FITTING INSTRUCTIONS

Toyota Prado 120/150 (Spare under) – T7T728



Max Towing Capacity: 3000kg	Towbar Weight: 20kg
Max Ball Load: 300kg	Wiring Harness Part #: 120-UNT236 150-UNT282




Tools Required:

- Spanners, Sockets, Torque Wrench

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar Centre Section	1	9.	M12 Flat Washer	22
2.	End Plate PS	1	10.	M8x1.25x35 Bolt	2
3.	End Plate DS	1	11.	M8 Shake Proof Washer	2
4.	Spacer 3mm	2	12.	M8 Flat Washer	2
5.	M12x1.25x35 Bolt	2	13.	Hitch Collar Cover	1
6.	M12x1.25x45 Bolt	12	14.	Pin & Clip	1
7.	M12x1.25 Nut	8	...	D-Shackles	2
8.	M12 Shake Proof Washer	14	...	Compliance Sticker	1

T7T728



Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owners Manual.
- This towbar is NOT to be drilled, cut, welded or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present

General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.
- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.
- If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change. If you are not sure, then please ask your towbar supplier

FITTING INSTRUCTIONS

Toyota Prado 120/150 (Spare under) – T7T728



Step 1 | Fit Towbar End Plate



Instructions	Tools	Torque Spec
<p>Loosely secure both towbar end plates to the chassis.</p> <ul style="list-style-type: none"> - Using 2x M12 Bolt, Flat and Shake Proof Washers into the captive nuts in the bottom of each chassis rail, through the rear most 2 holes in the end plate - Using 1x M8 Bolt, Flat and Shake Proof Washers into the captive nuts in the bottom of each chassis rail, through the forward most holes in the end plate <p>Tighten the bolts to hold the end plates against the chassis rails. DO NOT tighten to torque spec.</p>	Spanners, Sockets	NA

Step 2 | Determine if Spacers are Required




Instructions	Tools	Torque Spec
<p>Position the Towbar centre section between the two end plates.</p> <p>If there is more than approx. 3mm clearance between the parts on each side, then spacers will be required.</p> <p>If the clearance is less than this, spacers will not be required between the parts.</p>	NA	NA

FITTING INSTRUCTIONS

Toyota Prado 120/150 (Spare under) – T7T728



Step 3 | Secure Towbar Centre Section



Instructions	Tools	Torque Spec
<p>Secure Towbar Centre section to the end plates:</p> <ul style="list-style-type: none"> - Using 4x M12x45 Bolts, Shake Proof Washers, M12 Nuts, 8x M12 Flat Washers, and 1x Spacer (if required) per side. Loosely secure the towbar centre section between the end plates. Ensure centre section is right side up with the chain mount below the hitch receiver <p>Secure centre section to the chassis:</p> <ul style="list-style-type: none"> - Using 2x M12 Bolts, Flat and Shake Proof Washers, 2x Top Plates (1 on each bolt) between the towbar and chassis and 2x nut on M12 Nut on wire (inside the chassis) <p>When all hardware is in place, tighten all bolts (including those into the chassis rails) to the torque specified.</p>	<p>Spanner, Sockets, Torque Wrench</p>	<p>M12 = 100Nm M10 = 60Nm</p>

Step 4 | Apply door sticker

FITTING INSTRUCTIONS

Toyota Prado 120/150 (Spare under) – T7T728



Instructions	Tools	Torque Spec
Apply Towbar info label to the inside of the driver's side door Jam.	N/A	N/A



WARRANTY STATEMENT

The manufacturer of TAG branded products, warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us directly by email at warranty@tagtowing.com