

FITTING INSTRUCTIONS

Mitsubishi Outlander 11/2012-ON – T4C608




Max Towing Capacity: 2000kg	Towbar Weight: 25kg
Max Ball Load: 200kg	Wiring Harness Part #: UNT314



Tools Required:

- Screwdriver, Spanners, Sockets, Torque Wrench

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar – T4C608	1	6.	½" x 4½" UNC Bolt	3
2.	Ball Mount – L4045	1	7.	½" Flat Washer	6
3.	M10 x 1.25 x 35 Bolt	4	8.	½" Shake Proof Washer	3
4.	M10 Shake Proof Washer	4	9.	½" UNC Nut	3
5.	M10 Flat Washer	4			



Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owners Manual.
- This towbar is NOT to be drilled, cut, welded or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present

General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.
- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

FITTING INSTRUCTIONS

Mitsubishi Outlander 11/2012-ON – T4C608



- If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change. If you are not sure, then please ask your towbar supplier

FITTING INSTRUCTIONS

Mitsubishi Outlander 11/2012-ON – T4C608



Step 1 Removal of Bumper		
Instructions	Tools	Torque Spec
a. Remove scrivits and 10mm head bolt in wheel arches [Retain] b. Open tailgate and remove 4 x 10mm head bolts from top inside section of the bumper [Retain] c. Remove scrivits from bumper support bracket [Retain]	-Screwdriver	N/A

Step 2 Removal of Bumper		
Instructions	Tools	Torque Spec
a. Take bumper off from sides first then rearwards. b. Note: Disconnect rear sensors if installed. c. Remove crush cones from both sides. [Discard]	N/A	N/A

Step 3 Removing Spare Wheel and Exhaust from Hangers		
Instructions	Tools	Torque Spec
a. Remove all bolts from Towbar taking note of locations. b. Install towbar using long bolts through sides of subframe and bolting with nuts and washers provided. [Some adjustment to the Towbar may be required enabling it to fit between the subframe. c. Fit 4 x 10mm bolts with washers into captive nuts in bottom of subframe. d. Tighten all bolts to specified ratings using a torque wrench	-Torque Wrench -Spanner	M10- 60Nm UNC ½ - 125Nm

FITTING INSTRUCTIONS

Mitsubishi Outlander 11/2012-ON – T4C608



Step 4 Bumper Refitment		
Instructions	Tools	Torque Spec
a. Refit exhaust onto rear hangers. b. Bumper cut out to be done 115mm long x 90mm wide, bottom centre of bumper. c. Refit bumper and reconnect reverse sensors if equipped. d. Attach ball mount with pin and clip supplied. e. Attach rating sticker to drivers side door pillar.	-Air saw	N/A



WARRANTY STATEMENT

The manufacturer of TAG branded products, warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us directly by email at warranty@tagtowing.com