



### Make / Model HYUNDAI GETZ 3&5 DOOR

## Other

## Year 10/03 ON

## Part number T2Z506

Maximum towing capacity 700 kg

Maximum ball load 70 kg

Bar weight 12 kg

Fit with wiring harness part No.

# Fitting Instructions

### Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

#### General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

© Mikano industries Quality document No. Page **1** of **2** 

### HYUNDAI / GETZ / YEAR

- 1. REMOVE ALL BOLTS FROM TOWBAR.
- 2. REMOVE EXHAUST FROM REAR HANGER OF VEHICLE.
  - 2.1. FIT TOWBAR ONTO VEHICLE PLACING DRIVERS SIDE UP FIRST AND SECURING WITH M12 BOLTS AND WASHERS SUPPLIED MAKING SURE TO PLACE SPACER PLATE BETWEEN TOWBAR AND SUBFRAME.
  - 2.2. FIT PASSENGER SIDE WITH M12 BOLTS AND WASHERS SUPPLIED AND TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.
- 3. FIT BALL MOUNT USING M16 BOLTS AND WASHERS SUPPLIED AND TIGHTEN.
  - 3.1. REFIT EXHAUST ONTO REAR HANGER.
- 4. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

## Torque table for bolt tightening

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

© Mikano industries Quality document No. Page 2 of 2